



**OPERATING AND MAINTENANCE
PROCEDURE**
for
TELESCOPIC STANCHIONS
fitted to
AM-BOSS FIXED ACCESS LADDERS

STANCHIONS IN RETRACTED STATE:

After access hatch has been opened, pull up stanchion to the fullest height, turn and lower stanchion making sure locking pin comes to rest between the two retaining pins.

STANCHIONS IN EXTENDED STATE:

Lift and turn stanchion with locking pin clearing retaining pins, lower.

DO NOT DROP stanchion.

Close the hatch.

**INSPECTION OF THE SYSTEM MUST BE
CARRIED OUT ONCE A YEAR, AND
ACTION TAKEN AS AND WHEN
REQUIRED.**

TELESCOPIC STANCHIONS